

|            |                 |        |                                    |
|------------|-----------------|--------|------------------------------------|
| Product:   | HSC-AD          | Title: | HSC-AD-Tv2 Assembly Instruction EN |
| Date/ Rev: | 6/04/2021 Rev B | loc:   | CKS15226-eng                       |



**Required parts:**

- 1 Swirl diffuser in required neck size, complete with Control Module [2] and Guide Ring [3]
- 4 T-Element
- 5 Temperature Indicator



Groove for  
Temperature  
Indicator



Depress Guide Ring [3] and screw T-Element [4] into Control Module [2] until groove is level with the Module.



Insert Temperature Indicator [5] into the groove of T-Element [4].



Continue to turn the T-Element [3] until the Temperature Indicator [4] lines up with the desired temperature setting.

The indicator points to the heating temperature. The default setting is 26 °C. This applies to cases where no temperature has been specified. If the T-element is for example in the 26 degree setting, then the diffuser will be in heating mode (guide ring fully down for vertical discharge) at a supply air temperature of 26 degrees.

The ideal temperature setting can be determined using the HSC-AD selection tool available from:

<http://www.smartemp.com/product/87>